

Central Vacuum BOM for OVO-595ST-18V

#	Name	Description	QTY
1	COV-M7-NAD-V2	Cover	1
2	GAS-COU-M1F-V1	Cover Gasket	1
3	FIL-PU-M1F-V1	Protector filter	1
4	CYL-M7-B-V1	Cylinder	1
5	PIP-62	Elbow PVC Piping for bag	1
6	BRA-AIR-M7-V1	Support bracket for Air-in Pipe	1
7	PIP-8.3ALU-M7-V1	Air-in Pipe	1
8	GAS-PIP89	Cyclonic entry gasket	1
9	PIP-89	Cyclonic entry	1
10	FOAM-CYLM7	Cylinder foam	1
11	BRA-SOU-M7-V1	Support bracket for barrier	1
12	PLASOU-M7-V1	Sound proof plate	1
13	FOAM-COUMSER-BOT	Bottom cover foam	1
14	COV-M7-NAD-BOT-V1	Bottom cover	1
15	MUSUP-SDV1	Mural support	1
16	PAD-MUSUP-TOP-V4	Mural support gasket	2
17	BRA-MUSUP-M5	Steel support bracket	1
18	PLG-110/120 OR PLG-220/240	Power cord	1
19	PIP-STR/EG11 OR PIP-STR/SR6R1	Strain relief	1
20	PLAFIL-M7-V3	Filtration plate	1
21	GAS-MTR-4.2"	Motor gasket	1
22	MOT-PY27	Motor	1
23	GAS-MTRRING-4.2-V1	Motor ring gasket	1
24	POL-MTR-M5-V1	Connecting Rod for motor	3
25	MTRRING-4.2-V1	Motor ring round	1
26	GAS-PCB 6114-V1	PCB gasket	1
27	6114-19C1	PCB	1
28	LV-SOCKET	Low Voltage Connector	1
29	FD-12.5L-OVO	Disposable bag	1
30	PIP-39	Flanged slip coupling	1
31	GAS-PIP39	Gasket for Flanged slip coupling	1
32	INSP-90-ST-FF	Short 90° Elbow	1
33	INSV-UT47-BK	Utility valve	1
Fastener			
34	M4-13	Screw for PIP-90	4
35	M3-10	Screw for Bottom Cover	3
36	M5-16	Screw for POL-MTR	6
37	M4-20	Groud screw	1
38	M4-12	Screw for LV-SOCKET	2
39	M4-12	Stainless steel rivet	4
40	M4-12	Screw for BRA-AIR-M7-V1	2
41	M4-12	Screw for PIP-39	4
42	M3.2-6	Alu rivet	2
43	ST4.8-38	ST4.8-38	3
44	M4	Washer	4
45	M4	Nut	6
46	M4	Nylon washer	1
47	M4	Star washer	4
48	QUI-358	Wall rubber anchor	3

